



ITEM	PART NO.	DESCRIPTION	QTY.
1	850901	MOVEMENT	1
2	816816-10*	DIAL SCREW	2
3	816817-5*	SPRING WASHER	1
4	850899	POINTER	1
5	850914	MEMORY CRYSTAL	1
6	816820-10*	MAGNETIC DISC	1
7	816821-3*	MEMORY KNOB	1
8	816822-3*	MEMORY BASE	1
9	816823-3*	MEMORY POINTER	1
10	816824-3*	MEMORY SPRING	1
11	850905	GUARD	1
13	816818-10*	COVER SCREW	5
14	850909	COVER	1
15	850912	CASE, PLASTIC (not shown)	1
16	850958	DIAL SCALE	1
17	816826-10*	GUARD SCREW	3
18	850940	MOVEMENT SPACER	2
19	857025	CARDBOARD BOX (not shown)	1
20	850900	LEAF SPRING (not shown)	1
	812072	RUBBER GRIP (not shown)	1

LEGEND: * = QUANTITY/MULTI-PAK



THIS PRINT AND ALL INFORMATION APPEARING THEREON IS THE PROPERTY OF "STURTEVANT/RICHMONT". NEITHER THE PRINT NOR THE INFORMATION THEREON MAY BE REPRODUCED OR USED IN ANY MANNER WHATSOEVER OR DIVULGED TO ANY OTHER PERSON UNLESS SPECIFICALLY AUTHORIZED BY "STURTEVANT/RICHMONT".

PART DESCRIPTION: M D 250 850705-B
 DIAGRAM NO. & REV.