



TH – Tool Holder

Modell	Best.-Nr.	∅ mm	für Typ
TH001	Y61022-001	42	RRI-SP0502, RRI-SP11602, RRI-SP10902, RRI-SP21704, RRI-SP21104, RRI-SP20705, RRI-SP31706, RRI-SP31108, RRI-SP30710, RRI-SP30511, Y-41A(JQ), Y-46A(E)(JQ), Y-56A(E)(JQ), Y-61A(E)
TH002	Y61022-002	47	YS-E600, YS-E800, YS-E900, YS-E950, Tka60(A), Tka70(A), Tka80(A), YEX120(A), YEX150(A), RRI-30T(AT), RRI-40T(AT), RRI-50T(AT), RRI-60T(AT), RRI-30(A), RRI-40X(AX), RRI-50X(A), RRI-60(AX), YLTX50A, YLTX60A, YLTX50E, YLTX60E, YLT60AL(EL), YLTX70A(E), YLT70AL(EL), YLa60A(JQ), YLa70A(JQ), YLa80A(JQ), YLa60E(JQ), YLa70E(JQ), YLa80E(JQ)
TH003	Y61022-003	58	RRI-BS3, RRI-BS6, RRI-BS9, RRI-BI32T, RRI-BI55T, RRI-BI100T RRI-BI120T, RRI-BIM15(A)T, RRI-BIM25(A)T, RRI-BIM35T, RRI-BIM45T, Tka600(A), Tka700(A), Tka800, Tka90, Tka110, Tka120, RRI-70T(AT), RRI-80T, RRI-90T, RRI-70(A)/80/90, YLTX80E, YLT80EL, YLTX110E, YLT110EL, YLa90E, YLa110E, YLa120E, Y70E(JQ)
TH004	Y61022-004	73	YS-M500, YS-M700, YS-M900, YS-M1100, Tka1110, Tka1200, Tka1400, Tka1500, Tka150, YEX-1400, RRI-100T, RRI-130T, RRI-150T, YLTX120E, YLT120EL, YLTX140E, YLT140EL, YLa140E, Y-140(JQ)



TH – Tool Holder

Modell	Best.-Nr.	für Typ
TH005	Y61022-005	RRI-BIM-Serie RRI-BS-Serie RRI-BI-Serie RRI-BA-Serie



Weitere Infos
auf unserer
Website.
24/7