



- NOTES:
1. APPLY MAGNALUBE LUBRICANT TO THE KNURLED CUP POINT OF SET SCREW (816859) BEFORE ASSEMBLING.
 2. HANDLE (812134) & NOSE (812133) MUST WITHSTAND A MINIMUM OF 60 IN'LBS OF TORQUE IN THE COUNTER-CLOCKWISE DIRECTION BEFORE COMING APART.
 3. APPLY MAGNALUBE LUBRICANT TO THE GUIDE BALLS (816886), SLOTS OF SHAFT (812140) & DIMPLED INSERT (816852).
 4. LIGHTLY LUBRICATE INSIDE OF SPRING (812136) WITH MAGNALUBE.

INCLUDES:
 812151, HEX KEY
 857372, CARTON
 857182, INSTRUCTIONS

LEGEND: () = Quantity/Tool
 * = Quantity/Multi-Pak



THIS PRINT AND ALL INFORMATION APPEARING THEREON IS THE PROPERTY OF STURTEVANT/RICHMOND - NEITHER THE PRINT NOR THE INFORMATION HEREON MAY BE REPRODUCED OR USED IN ANY MANNER WHATSOEVER OR DIVULGED TO ANY OTHER PERSON UNLESS SPECIFICALLY AUTHORIZED BY STURTEVANT/RICHMOND.

PART DESCRIPTION
 P N M — S

DIAGRAM NO. & REV.
 810007-P

DIVISION OF RYSON CORPORATION