

PARTS LIST

No.	Name of Parts	Per Set	Parts No.	No.	Name of Parts	Per Set	Parts No.
1	Motor Case Assy.	1set	0086 0011 01 99	13	Liner Cap	1	0086 0423 00 00
	(a)Motor Case	1	0086 0011 01 00	14	Liner Upper Plate Assy.	1set	0135 0424 00 99
	(b)Spring Roll Pin(3×6)	1	9250 1043 00 00		(a)Liner Upper Plate	1	* ↑
	(c)Hose Joint	1	0237 0113 00 00	(b)*O"Ring(N28)	1	9010 4029 00 00	
	Throttle Bushing Assy.	1set	2058 0104 00 99	15	Liner Assy.	1set	0135 0425 00 99
	(d)Throttle Bushing	1	* ↑		(a)Liner	1	* ↑
	(e)*O"Ring(N15)	3	9010 4008 00 00	(b)FF Pin(2.5×6)	4	8051 1072 00 00	
	Throttle Rod Bushing Assy.	1set	0078 0105 00 99	16	Relief Valve	1	0086 0245 00 00
	(f)Throttle Rod Bushing	1	* ↑		17	Spring Guide(B) Assy.	1set
	(g)*O"Ring(No. 3)	1	9010 3021 00 00	(a)Spring Guide(B)		1	* ↑
	Throttle Rod Assy.	1set	2058 0106 00 99	(b)*O"Ring(0.7×2×3.4)	1	9010 6020 00 00	
	(h)Throttle Rod	1	* ↑	18 ²	Main Shaft(A) YX-380A	1	0086 0614 03 51
	(i)*O"Ring(N2)	1	9010 4001 00 00	18 ³	Main Shaft(B) YX-380B	1	0086 0614 03 52
	(j)Snap Ring(ETW-2.8)	1	9040 5008 00 00	18 ⁶	Main Shaft(P)Assy. YX-380	1set	0086 0614 05 59
	(k)Throttle Knob	1	2024 0153 00 00	19	Blade	2	0086 0719 02 00
	(l)Spring Roll Pin(1.5×14)	1	9250 1005 00 00		20	Spring(3.4×22.7)	2
	(m)G Pin(3×24)	1	8410 6024 00 00	21		Liner Lower Plate Assy.	1set
	Reverse Valve Assy.	1set	0086 0005 00 99		(a)Liner Lower Plate	1	* ↑
	(n)Reverse Valve	1	* ↑	(b)Spring Roll Pin(3×8)	1	9250 2022 00 00	
	(o)*O"Ring(P7)	1	9010 1005 00 00	22	Oil Plug	1	0081 0010 00 00
	(p)Spring(13.4×9)	1	8020 1209 00 00		23	*O"Ring(N3)	1
(q)Reverse Lever	1	2014 0007 01 00	24	Oil Stop Cap Assy.		1set	0081 0602 00 99
(r)FF Pin(2×22)	1	8055 1050 00 00		(a)Oil Stop Cap	1	* ↑	
(s)Spring(3×6)	1	8020 1008 00 00	(b)*O"Ring(N2)	1	9010 4001 00 00		
(t)Ball(M3)	1	9150 1003 00 00	(c)Backup Ring(N2)	1	9090 2001 00 00		
2	Silencer Assy.	1set	0081 0053 00 99	25	*O"Ring(1×29.2×31.2)	1	9010 6022 00 00
	3	Spring Roll Pin(3×16)	1		9250 1050 00 00	26	*O"Ring(2.3×11.8×16.4)
4	Hanger	1	0004 0017 00 00	27	Backup Ring(12×16×0.8)		1
	5	Upper Plate Spacer	1		0086 0301 00 00	28	*O"Ring(1.3×28.7×31.3)
6		Upper Plate Assy.	1set	0086 0303 01 99	29		Hammer Case Assy.
	(a)Upper Plate	1	0086 0303 01 00	(a)Hammer Case		1	0086 0401 00 00
	(b)Ball Bearing(#697)	1	9100 1060 00 00	(b)Main Shaft Bushing		1	0081 0612 00 00
7	Cylinder Assy.	1set	0086 0304 01 99	(c)Socket Plug(PT 1/8)	1	8210 5001 00 00	
	(a)Cylinder	1	* ↑	30	Washer (12.5×18×0.5)	1	8041 5011 00 00
	(b)Spring Roll Pin(2×6)	1	9250 1011 00 00		YX - 380A & 380B		
(c)Spring Roll Pin(2×14)	1	9250 1017 00 00	31	(a)Ball(1/8)	1	9150 3009 00 00	
8	Rotor	1	0086 0305 00 00	31	(b)Bit Chuck	1	2057 0414 00 00
	9	Vane	6	0086 0306 00 00	31	(c)Spring(13.5×11.2)	1
10		Lower Plate Assy.	1set	0086 0307 01 99	31	(d)Spring Washer	1
	(a)Lower Plate	1	0086 0307 01 00	31	(e)Retaining Ring(10×1)	1	8030 1009 00 00
	(b)Ball Bearing(#6900)	1	9100 1046 00 00	Optional Parts			
	(c)FF Pin(2.5×6)	1	8055 1053 00 00	18 ¹	Main Shaft(3/8sq)	1	0086 0614 03 01
11	Lower Plate Spacer	1	0086 0311 01 00				
	12	Liner Case(A) Assy.	1set	0086 0422 03 98			
(a)Liner Case		1	* ↑				
(b)Screw(M3×8)		1	9480 2024 00 00				
(c)Rubber Plate		2	0259 0047 00 00				
(d)Spring(3.2×6)		1	8020 1288 00 00				
(e)Screw(M4×5)		1	9480 2002 00 00				
(f)*O"Ring(N32)	1	9010 4014 00 00					

The part marked "*" can not be supplied individually. So please order it as a unit of assembly shown by arrow mark (↑).