

PARTS LIST

No.	Name of Parts	Per Set	Parts No.	No.	Name of Parts	Per Set	Parts No.
1	Motor Case Assy.	1set	0083 0011 01 99	18	Blade	2	0080 0719 02 00
	(a)Motor Case	1	0083 0011 01 00	19	Spring	2	8020 1253 00 00
	(b)Hose Joint	1	0237 0113 00 00	20	Liner Lower Plate Assy.	1set	0135 0426 00 99
	(c)Reverse Bushing	1	0080 0004 00 00		(a)Liner Lower Plate	1	* ↑
	(d)*O*Ring	2	9010 4008 00 00		(b)Spring Roll Pin	1	9250 2022 00 00
	Reverse Valve Assy.	1set	0080 0005 00 99	21	Oil Plug	1	0081 0010 00 00
	(e)Reverse Valve	1	* ↑	22	*O*Ring	1	9010 4025 00 00
	(f)*O*Ring	1	9010 4006 00 00	23	Oil Stop Cap Assy.	1set	0081 0602 00 99
	(g)Ball	1	9150 4002 00 00		(a)Oil Stop Cap	1	* ↑
	(h)Spring	1	8020 1066 00 00		(b)*O*Ring	1	9010 4001 00 00
	Reverse Lever Assy.	1set	0932 0007 00 99	(c)Backup Ring	1	9090 2001 00 00	
	(i)Reverse Lever	1	* ↑	24	*O*Ring	1	9010 6022 00 00
	(j)*O*Ring	1	9010 1006 00 00	25	*O*Ring	1	9010 6019 00 00
	(k)Spring Roll Pin	1	9250 1021 00 00	26	Backup Ring	1	9090 1010 00 00
	(l)AA Pin	1	8051 3057 00 00	27	*O*Ring	1	9010 6010 00 00
	(m)Throttle Lever	1	0931 0110 00 00	28	Spacer	1	0083 0119 00 00
	(n)Spring Roll Pin	1	9250 5001 00 00	29	Bevel Gear Shaft	1	0118 0640 00 00
2	Silencer Assy.	1set	0081 0053 00 99	30	Bearing Cap	1	0083 0618 00 00
3	Spring Roll Pin	1	9250 1050 00 00	31	Ball Bearing	2	9100 1036 00 00
4	Hanger	1	0004 0017 00 00	32	ST-Packing	1	8011 1047 00 00
5	Upper Plate Assy.	1set	0080 0303 02 99	33	ST-Packing	1	8011 1048 00 00
	(a)Upper Plate	1	0080 0303 02 00	34	ST-Packing	1	8011 1049 00 00
6	Cylinder Assy.	1set	0080 0304 01 99	35 ¹	Spindle YX-500C	1	0118 0641 00 00
	(a)Cylinder	1	* ↑	35 ²	Spindle(A) Assy. YX-500CA	1set	0118 0614 01 99
(b)Spring Roll Pin	2	9250 1011 00 00	(a)Spindle(A)		1	* ↑	
7	Rotor	1	0080 0305 00 00		(b)Ball	1	9150 1005 00 00
8	Vane	6	0080 0306 00 00	(c)Band	1	2032 0415 00 00	
9	Lower Plate Assy.	1set	0086 0307 00 99	36	FF Pin	1	8051 1235 00 00
	(a)Lower Plate	1	0086 0307 00 00	37	Washer	1	8040 1022 00 00
	(b)Ball Bearing	1	9100 1046 00 00	38	Washer	1	8040 1071 00 00
10	Lower Plate Spacer	1	0083 0311 00 00	39	ST-Packing	1	8011 1044 00 00
	(c)FF Pin	1	8055 1053 00 00	40	ST-Packing	1	8011 1045 00 00
11	Liner Case(A) Assy.	1set	0083 0422 04 98	41	ST-Packing	1	8011 1046 00 00
	(a)Liner Case	1	* ↑	42	Hammer Case Cap Assy.	1	0083 0412 01 99
	(b)Adjust Bolt	1	0083 0522 00 00	43	Washer	1	8041 5011 00 00
	(c)Rubber Plate	2	0259 0047 00 00	44	Hammer Case Assy.	1set	0083 0401 00 99
	(d)Spring	1	8020 1288 00 00		(a)Hammer Case	1	0083 0401 00 00
	(e)Screw	1	9480 2031 00 00		(b)Spindle Bushing(B)	1	0118 0643 00 02
(f)*O*Ring	1	9010 4014 00 00	(c)Socket Plug	1	8210 5001 00 00		
12	Liner Cap	1	0086 0423 00 00	45	Hexagon Set Bolt	2	8070 7008 00 00
13	Liner Upper Plate Assy.	1set	0135 0424 01 99	46	S-Packing	1	0083 0003 00 00
	(a)Liner Upper Plate	1	* ↑	47	Hexagon Socket Bolt	4	8070 3112 00 00
14	Liner Assy.	1set	0080 0425 03 99	48	Spring Washer	4	9200 3004 00 00
	(a)Liner	1	* ↑	49	Cover Plate	1	0083 0014 00 00
15	Relief Valve	1	0081 0245 00 00	50	Set Screw	2	9460 2003 00 00
	(b)FF Pin	4	8051 1072 00 00				
16	Spring Guide(B) Assy.	1set	0080 0510 00 99				
	(a)Spring Guide(B)	1	* ↑				
17	Liner Shaft	1	0083 0796 01 00				
	(b)*O*Ring	1	9010 6020 00 00				

The part marked "*" can not be supplied individually. So please order it as a unit of assembly shown by arrow mark (↑).